



**CHRIST**  
(DEEMED TO BE UNIVERSITY)  
BANGALORE, INDIA

# Guidelines

- Students are supposed to login with your Christ university ID
- Kindly mute your microphones and switch off your video for better connectivity.
- If there is delay in the presentation due to internet connectivity please wait.
- If you would like to say anything please use the chat box.
- Kindly don't use mobile phones during the class hours.

## MISSION

CHRIST is a nurturing ground for an individual's holistic development to make effective contribution to the society in a dynamic environment

## VISION

Excellence and Service

## CORE VALUES

Faith in God | Moral Uprightness  
Love of Fellow Beings  
Social Responsibility | Pursuit of Excellence



**CHRIST**  
(DEEMED TO BE UNIVERSITY)  
BANGALORE, INDIA

# **Course Name : Basics of Civil Engineering and Engineering Mechanics Laboratory**

## **Course Code : CE134/234**

### **MISSION**

CHRIST is a nurturing ground for an individual's holistic development to make effective contribution to the society in a dynamic environment

### **VISION**

Excellence and Service

### **CORE VALUES**

Faith in God | Moral Uprightness  
Love of Fellow Beings  
Social Responsibility | Pursuit of Excellence

## Experiment No 3 : Determination of Fineness of Cement.

- **Aim / Objective** : To determine the fineness of the given cement sample
- **Equipments Used** : IS 90 micron sieve, digital weighing machine and cement sample .

# Theory

- **The fineness of cement has an important bearing on the rate of hydration and hence on the rate of gain of strength and also on the rate of evolution of heat. Finer cement offers a greater surface area for hydration and hence faster the development of strength.**

## **Procedure**

- 1) Weigh about 100gms of given cement sample ,W1**
- 2) Place it on 90micron sieve and cover it with a lid and pan at the bottom**
- 3) Carry out process of sieving such that each and every particle undergoes the process of sieving**
- 4) Note down the weight retained on 90 micron sieve,W2**
- 5) Calculate the fineness of of the cement sample using the formula.**

# Observations & Calculations

Particulars	Trial 1	Trail 2	Trial 3
Weight of sample taken W1	100grams	100grams	100grams
Weight retained on 90 micron sieve, W2	6	4	5
Fineness of cement			

**The fineness of cement is calculated as follows**

$$\textit{Fineness of Cement} = (W2 / W1) * 100$$

**Result:** The fineness of given cement sample is \_\_\_\_\_%

# THANK YOU